



# Amplitude™ Epsilon™

Nonwoven cellulose/polyester hydroentangled wipe

### Description

Made of 55% special grade blue cellulose and 45% polyester hydroentangled to form a wipe with improved cleanliness and excellent sorbency. The cellulose uses a dye-fast color, to minimize color bleeding. Blue color allows for differentiation in critical areas. Good for wet areas requiring spill pickup and cleanup.

### Features and Benefits

- Dye-fast blue color allows for differentiation
- Low levels of particles and extractables
- Excellent sorbency
- Strong and durable

### Applicability

The information presented here is applicable to the part numbers shown below as well as to any product containing the same materials and produced under the same conditions, regardless of product size or packaging configuration. Please contact a Contec sales representative for more details.

AMEP0001, AMEP0002

### Technical Data

Attribute; (units)	Value **	Test Method
Basis weight; (g/m <sup>2</sup> )	73	
Sorbency in water		
Intrinsic; (mL/g)	4.0	IEST-RP-CC004.2, Sec. 7.1
Extrinsic; (mL/m <sup>2</sup> )	288	IEST-RP-CC004.2, Sec. 7.1
Sorptive rate; (seconds)	1.0	
Non-volatile residue, NVR		IEST-RP-CC004.2, Sec. 6.1.2
In deionized water; (g/m <sup>2</sup> )	0.014	
In isopropanol; (g/m <sup>2</sup> )	0.009	
Specific ions		IEST-RP-CC004.2, Sec. 6.2.2
Sodium; (ppm)	8.0	
Chloride; (ppm)	12.6	
Particles, readily releasable		IEST-RP-CC004.2, Sec. 5.1
P ≥ 0.3µm; (x10 <sup>6</sup> /m <sup>2</sup> )		
P ≥ 0.5µm; (x10 <sup>6</sup> /m <sup>2</sup> )	23.1	
Fibers > 100µm; (x10 <sup>3</sup> /m <sup>2</sup> )	24.5	IEST-RP-CC004.2, Sec. 5.2

\*\* ND = None detected; levels are below detection limit of test equipment

### Notes:

- 1) Data shown are typical values and should not be used as product specifications.
- 2) Valid product comparisons may only be obtained through side-by-side testing in the same test facility, under similar conditions.
- 3) Current and/or comparison data may be available. Please contact a Contec sales representative for details.

Revision date: 05/13/08



P.O. Box 530  
 Spartanburg, SC 29304 USA  
 Phone: +1-864-503-8333  
 Fax: +1-864-503-8444  
 Toll free US, Canada, PR: 1-800-289-5762

**Customer Service**  
 United States: 1-866-855-4682  
 Europe/Asia: +1-864-699-8257  
 e-mail: wipers@contecinc.com  
 www.contecinc.com