



PROSAT[®] 911EB Wipes, Sterile

Meltblown Polypropylene with 70% USP Grade IPA, 30% DI Water

Description

The PROSAT PS-911EB consists of polypropylene wipes saturated with a solution of 70% isopropanol alcohol and 30% deionized water in a resealable pouch. The pouch opens easily and the wipes are readily dispensed.

The PROSAT PS-911EB utilizes a meltblown polypropylene wipe which is exceptionally clean, being free from additives of any kind.

Features and Benefits

- Compatible with ISO Class 5 cleanrooms
- Very low concentration of sodium
- Increase solvent control and accountability
- Reduce VOC emissions
- Sterile per AAMI Guidelines

Applicability

The information presented here is applicable to the part numbers shown below as well as to any product containing the same materials and produced under the same conditions, regardless of product size or packaging configuration. Please contact a Contec sales representative for more details.

PS-911EB, PSPP0039

Technical Data

Wipe material	Polypropylene	
Wipe construction	Meltblown nonwoven	
Solution of saturation; (blend ratio and constituents)	70% isopropanol alcohol/ 30% deionized water	
Solvent Grade	USP	
Attribute; (units)	Value **	Test Method
Basis weight; (g/m ²)	36	Contec Method
Non-volatile residue, NVR		IEST-RP-CC004.3, Sec. 7.1.2
In deionized water; (g/m ²)	0.01	
In isopropanol; (g/m ²)	0.07	
Specific ions		IEST-RP-CC004.3, Sec. 7.2.2
Sodium; (ppm)	3.0	
Chloride; (ppm)	5.0	
Particles, readily releasable		IEST-RP-CC004.2, Sec. 5.1
P ≥ 0.5µm; (x10 ⁶ /m ²)	5.1	
Fibers > 100µm; (x10 ³ /m ²)	6.3	IEST-RP-CC004.2, Sec. 5.2
Saturation volume tolerance;		
< 300 mL	+/- 12%	
300 -1666 mL	+/- 3%	
> 1666 mL	+/- 50 mL	

** ND = None detected; levels are below detection limit of test equipment

Notes:

- 1) Data shown are typical values and should not be used as product specifications.
- 2) Valid product comparisons may only be obtained through side-by-side testing in the same test facility, under similar conditions.
- 3) Current and/or comparison data may be available. Please contact a Contec sales representative for details.

Revision date: 05/09/11



P.O. Box 530
Spartanburg, SC 29304 USA
Phone: +1-864-503-8333
Fax: +1-864-503-8444
Toll free US, Canada, PR: 1-800-289-5762

Customer Service
United States: 1-866-855-4682
Europe/Asia: +1-864-699-8257
e-mail: wipers@contecinc.com
www.contecinc.com