



CONSTIX[®] Swabs
SC Series Cotton Swabs
(Part Numbers: SC-1, SC-2, SC-3, SC-4, SC-7, SC-9)

Description

The SC Series cotton swabs consist of high quality, long staple-length cotton, tightly wrapped and shaped on both ends of high strength, wound paper handles (except the SC-9 which has a wood handle). The heads are held to the handles using a methyl-cellulose binder.

The high quality cotton fibers provide excellent particle entrapment and retention, as well as exceptional absorbency of most solvents and solutions. The heads are very tightly wrapped and shaped using methyl-cellulose binder which minimizes fiber shedding, while maintaining low levels of extractable residue. The SC series cotton swabs are absorbent to most common solvents including isopropyl alcohol, acetone, and is ideal for use with aqueous based solutions.

Physical Information

Dimensions:

- SC-1 0.20" dia. x 0.5" pointed/pointed double-ended cotton swab, paper handle, 3" total length
- SC-2 0.20" dia. x 0.6" round/round double-ended cotton swab, paper handle, 3" total length
- SC-3 0.10" dia. x 0.5" round/round double-ended cotton swab, paper handle, 3" total length
- SC-4 0.08" dia. x 0.3" hard sharp point double-ended cotton swab, paper handle, 3" total length
- SC-7 0.10" dia. x 0.4" sharp point double-ended cotton swab, paper handle, 3" total length
- SC-9 0.20" dia. x 0.6" single round cotton swab, wood handle, 6" total length

Packaging:

- SC-1 25 swabs/cellophane sleeve, 50 sleeves/box, 3 boxes/case (3,750 swabs/case)
- SC-2 25 swabs/cellophane sleeve, 50 sleeves/box, 3 boxes/case (3,750 swabs/case)
- SC-3 25 swabs/cellophane sleeve, 100 sleeves/box, 2 boxes/case (5,000 swabs/case)
- SC-4 25 swabs/cellophane sleeve, 100 sleeves/box, 2 boxes/case (5,000 swabs/case)
- SC-7 25 swabs/cellophane sleeve, 100 sleeves/box, 2 boxes/case (5,000 swabs/case)
- SC-9 100 swabs/poly bag, 10 bags/box, 2 boxes/case (2,000 swabs/case)

Technical Data

Specific technical data available upon request.

Notes:

- 1) Data shown are typical values and should not be used as product specifications.
- 2) Valid product comparisons may only be obtained through side-by-side testing in the same test facility, under similar conditions.
- 3) Current and/or comparison data may be available. Please contact a Contec sales representative for details.

Revision date: 06/20/05



P.O. Box 530
Spartanburg, SC 29304 USA
Phone: +1-864-503-8333
Fax: +1-864-503-8444
Toll free US, Canada, PR: 1-800-289-5762

Customer Service
United States: 1-866-855-4682
Europe/Asia: +1-864-699-8257
e-mail: wipers@contecinc.com
www.contecinc.com