

EasyCurve™ Mop

Designed specifically for critical and controlled environments, Contec's **EasyCurve™ Mop** consists of a flat, fabric-laminated mop head attached to a curved, stainless steel frame to provide superior performance, ease of use, and effectiveness compared to any other all-surface cleaning system.

The 14" (35.5cm) disposable mop head securely attaches to the curved frame by a unique system of latching tabs, but remains simple and easy to remove. The combination of the curved mop face and the pivoting connector results in effortless surface contact and outstanding maneuverability, making the EasyCurve an ideal cleaning tool for ceilings, walls and floors. Available in non-sterile and validated sterile versions.

The EasyCurve mop head frame attaches to a 60" (152.4cm) fixed-length stainless steel handle. For added convenience and flexibility, telescoping handles in both autoclavable aluminum and all-stainless steel are also available.

The EasyCurve mop uses a separate "sling" style wringer that installs over an autoclavable bucket to completely and easily remove liquid from the mop head. Since the wringer is not on the handle like traditional sponge roller mops, weight and resulting operator fatigue are significantly reduced. A stainless steel trolley with 4 autoclavable casters is available for added mobility. Additional hardware can be used to create a multi-bucket system.

Applications

Designed for use in pharmaceutical and medical device manufacturing plants, hospitals, compounding pharmacies, and other similar critical or controlled environments, the EasyCurve is an outstanding all-surface mop for use on ceilings, walls and floors. All components of the EasyCurve system are autoclavable. An ideal upgrade alternative in applications where sponge roller and self-wringing style mops are currently used.



With its absorbent and drip-free polyurethane foam mop head, the EasyCurve™ mop is an ideal choice for cleaning ceilings, walls and floors.

FEATURE	BENEFIT
Hydrophilic polyurethane foam mop head	<ul style="list-style-type: none"> • Very absorbent and drip-free • Compatible with most common solutions and solvents
Laminated fabric face	<ul style="list-style-type: none"> • Clean and durable for most surfaces
Disposable flat-form mop head	<ul style="list-style-type: none"> • Economical and easy to install without tools
Lightweight mop head and handle	<ul style="list-style-type: none"> • Weighs much less than roller-type and self-wringing mops • Significantly reduces operator fatigue
All components are autoclavable	<ul style="list-style-type: none"> • Ideal for the widest range of applications and cleaning and disinfecting solutions

*U.S. Design Patent
No. D586,966

Continued on reverse side

2726 shown with
trolley 2728



P.O. Box 530 • Spartanburg, SC 29304 USA
+1-864-503-8333 • fax: +1-864-503-8444
Toll Free: 1-800-289-5762
www.contecinc.com • e-mail: wipers@contecinc.com

FEATURE	BENEFIT
Curved, pivoting mop frame	<ul style="list-style-type: none"> • Provides effortless contact with surfaces • Ensures complete and uniform contact with all surfaces • Ensures proper “lift and pull” cleaning technique
Separate wringer in bucket, not on mop handle	<ul style="list-style-type: none"> • Removes weight from mop handle • Greatly reduces operator fatigue
Sling-style wringer	<ul style="list-style-type: none"> • Easy and simple to use • No moving parts • Self-adjusting for uniform contact and pressure • Effectively wrings mop and removes contaminants from the mop head • Compatible with most common solutions and solvents



*U.S. Design Patent No. D586,966

Part #	Description	Packaging
EasyCurve™ Mop and Hardware		
EZMP0100	EasyCurve disposable mop head, 14 x 4.25 x 0.75" (35.5 x 10.8 x 1.9cm)	4 EA/BG, 12 BGS/CS
EZMP0150	EasyCurve disposable mop head, sterile, 14 x 4.25 x 0.75" (35.5 x 10.8 x 1.9cm), individually packaged	4 IBS/OB, 12 OBGS/CS
2724	EasyCurve pivoting mop head frame, stainless steel	1/each
2725	Interchangeable mop handle, 60" (152.4cm), stainless steel, lightweight, 1 piece, autoclavable	1/each
2643	Interchangeable mop handle, 50" (127cm) extends to 92" (233.7cm), anodized aluminum, autoclavable	1/each
2645	Interchangeable mop handle, 50" (127cm) extends to 92" (233.7cm), stainless steel, autoclavable	1/each
Bucket Systems		
2726	EasyCurve bucket w/ Slinger and frame, polypropylene, 6.5 gal. (25L)	1/each
2728	Stainless steel bucket trolley (caster base w/ 4 autoclavable casters)	1/each
2729	Stainless steel connecting kit (for multibucket system)	1/each
2743	Twin divided bucket w/ Slinger and frame; 5.3 gallon (20L) total volume, includes one cover, 4 non-autoclavable casters, polypropylene (seafoam)	1/each
2622	2 6.5 gal. (25L) polypropylene buckets (1 red, 1 blue) w/ 1 Slinger and frame, stainless steel multibucket trolley w/ 4 autoclavable casters	1/each

Replacement Parts

2727	Replacement Slinger insert, 100% polyester	1/each
UBKT0001	Autoclavable polypropylene bucket, 6.5 gal. (25L), blue	1/each
UBKT0002	Autoclavable polypropylene bucket, 6.5 gal. (25L), red	1/each



Part Number 2743 includes:
 Twin divided bucket (1)
 Slinger and frame (1)
 Cover (1)
 Casters (4) not pictured

Caster bases can be connected to form a multi-bucket system.
Pictured in photo:
 2726 EasyCurve™ Bucket w/ Slinger™ and Frame (1)
 UBKT0002 Autoclavable Plastic Bucket, Red (1)
 2728 Stainless Steel Bucket Trolley (2)
 2729 Stainless Steel Connecting Kit (1)

Part Number 2622 includes:
 Stainless steel cart (1)
 Autoclavable Plastic Bucket, Red (1)
 Autoclavable Plastic Bucket, Blue (1)
 Stainless Steel Connecting Kit (1)
 Slinger and frame (1)