

SATWipes® Solvent Wiping System

Contec's SATWipes Solvent Wiping System is custom engineered to meet your surface preparation needs, whatever your solvent requirements may be. SATWipes wipes are ideal for paint, sealant and adhesive preparation; dirt, grease, and oil removal; and composite surface wiping.

The SATWipes system was developed by Contec along with automotive and aerospace professionals as a better way to wipe surfaces while greatly reducing solvent emissions, solid waste, worker exposure, and costs. The SATWipes system consists of pre-wetted wipes in a convenient, re-closable canister. The wipes are dispensed from a roll inside the canister as needed. The reusable and self-closing canister prevents the presaturated wipes from drying out and keeps them close at hand.

Name Your Solvent

For maximum effectiveness, the combination of wipers and solvents is customized to the requirements of the task. SATWipes wipes can be saturated with virtually any solvent—MEK, MPK, Toluene, DS-108, Naphtha blends, even IPA and Acetone. We specialize in aerospace-approved solvents, and have created custom-blends for many manufacturers, suppliers, and MROs. Solvent-specific, color-coded labeling is available. Different wipe materials are available for a variety of applications.

Choose Your Fabric

Contec's wiping material substrates are first-quality nonwoven and knitted fabrics, not rags or shop towels. Choose from meltblown polypropylene, spunbond or spunlace in various fiber compositions.

Benefits of Presaturated Wipes

- Simplifies solvent control and governmental reporting
- Improves operator safety
- Improves consistency and control of solvent wiping processes
- Improves productivity and convenience
- Significantly reduces VOC emissions
- Significantly reduces solvent usage
- Significantly reduces hazardous waste stream costs
- Reduces process costs
- Reduces environmental impact

Specifications

The SATWipes Solvent Wiping System conforms to the following aerospace specifications: AMS 3819, BMS 15-5, BSMS-88-001, DMS 1820, GC110LG, SS9170/681 and Pratt & Whitney: PMC 9094, PMC 1820, PMC 1914.



New product labels

CONTEC

P.O. Box 530 • Spartanburg, SC 29303 USA
1-864-503-8333 • fax 1-864-503-8444
Toll free US, Canada, PR 1-800-289-5762
www.contecinc.com • e-mail:surfaceprep@contecinc.com