

TuffStuff™

Critical Task Wipes for Various Environments

TuffStuff Wipes are high quality critical task wipes. Available in Light, Medium and Heavy Duty, these wipes are solvent resistant and maintain their strength even when wet. TuffStuff wipes offer exceptional durability and cleanliness making them ideal for critical cleaning in biotech and pharmaceutical industries as well as equipment and production line maintenance.

TuffStuff Wipes are available in multiple sizes, weights, and packaging configurations to meet the various customer needs.

The expanded range includes TuffSat, consisting of heavy duty dry wipes, quarterfolded in a tub that can be saturated with cleaning solution. This versatile option allows wipes to be customized with the correct cleaning solution for that particular environment.



FEATURES	BENEFITS
Hydroentangled nonwoven wipes	<ul style="list-style-type: none"> • Provide strong, durable wipes without the use of binders • Highly sorbent without the use of surfactants • Low linting
Light, medium and heavy duty wipes available	<ul style="list-style-type: none"> • Allows user to match the ideal wipe for the specific application
Various packaging configurations	<ul style="list-style-type: none"> • Choice of pop-up, perforated rolls and quarterfolded wipes
Multiple wipe sizes	<ul style="list-style-type: none"> • Various wipe sizes allow optimum selection for each job
Performance and strength	<ul style="list-style-type: none"> • Ideal for general cleaning applications or applying solvents • Offers strength wet or dry, no residues or binders left behind

Category	Strength	Abrasion Resistance	Thickness	Absorption Capacity
Light Duty	• •	• •	• • • • •	• • • • •
Medium Duty	• • • •	• • • •	• • •	• • •
Heavy Duty	• • • • •	• • • • •	• • • •	• • • •

TuffStuff™ Heavy Duty Wipes

TuffStuff heavy duty wipes are ideal for tough cleaning and maintenance tasks. These wipes offer an excellent combination of sorbency and durability. They are very strong wet or dry and are ideal for heavy duty cleaning with solvents or cleaners.

Applications:

- Tough cleaning and maintenance tasks, such as cleaning rough surfaces and scrubbing
- Process Equipment maintenance and cleaning
- Cleaning and wiping down parts, equipment and machinery
- Surface preparation with solvents
- Low lint glass cleaning



Construction:

- Cellulose for superior sorbency, reinforced with polyester for superior strength
- Hydroentangled for cleanliness and durability
- Very strong wet or dry
- No binders or adhesives
- Creped to provide soft feel
- Available in white or blue

Part No.	Description	Quantity
Heavy Duty Creped White		
TSWC0917	TuffStuff Heavy Duty, cellulose/polyester wipes, creped white, pop-up dispenser box, 9" x 16.5" (23 x 42cm)	100 wipes/box; 8 boxes/case
TSWC1214	TuffStuff Heavy Duty, cellulose/polyester wipes, creped white, roll-in dispenser box, 12" x 13" (30 x 33cm)	500 wipes/roll
TSWC1217	TuffStuff Heavy Duty, cellulose/polyester wipes, creped white, double pop-up dispenser box, 12" x 16.5" (30 x 42cm)	125 wipes/box; 2 boxes/case
C1C1217Q	TuffStuff Heavy Duty, cellulose/polyester wipes, creped white, quarterfolded, 12" x 17" (30 x 42cm)	500 wipes/bag; 2 bags/case
Heavy-Duty Creped Blue		
TSBC1213	TuffStuff Heavy Duty, cellulose/polyester wipes, creped blue, quarterfolded, 12" x 13" (30 x 33cm)	50 wipes/bag; 10 bags/case

TuffSat

In addition to the dry TuffStuff range, TuffSat provides large heavy duty textured wipes that are quarterfolded and in a tub ready to be presaturated with a cleaning solution. This is ideal for customers looking to eliminate spray bottles. The tub keeps the wipes saturated for extended periods of time and can be reused.

Not recommended for highly evaporative solvents.

Application:

- Cleaning of surfaces with detergents or cleaning solutions
- Tough cleaning tasks that benefit from a textured wipe or require a scrubbing wipe to enhance cleanability.

Construction:

- Textured fabric
- Thick and highly sorbent
- Large quarterfolded wipes
- No binders or surfactants that can contaminate surfaces



Part No.	Description	Quantity
TuffSat		
TSWT1217	TuffStuff Heavy Duty, cellulose/polyester wipes, textured white, quarterfolded, 12" x 17" (30 x 43cm)	50 wipes/bag; 18 bags/case
TSCN0001	TuffSat Dispenser Tub	4 each/case

TuffStuff™ Medium Duty Wipes

For moderate cleaning and maintenance tasks, TuffStuff medium duty wipes offer excellent strength and absorption. Medium duty wipes have good strength wet or dry. They are bulky, durable and can stand up to many cleaning tasks.

Applications:

- General maintenance and industrial jobs
- Cleaning up soil, oils, grime, solvents and lubricants
- Wiping surfaces and tools
- Applying solvents and thinners
- General glass cleaning

Construction:

- Medium weight with a good balance of cellulose and polyester
- Provides a good combination of sorbency and strength
- Hydroentangled for durability and cleanliness
- Contains no binders or adhesives
- Creped to provide soft feel
- Available in white



Part No.	Description	Quantity
Medium Duty Creped White		
TSWL1213	TuffStuff Medium Duty, cellulose/polyester wipes, creped white, quarterfolded, 12" x 13" (30 x 33cm)	50 wipes/bag; 18 bags/case
TSWL1217	TuffStuff Medium Duty, cellulose/polyester wipes, creped white, quarterfolded, 12" x 17" (30 x 42cm)	50 wipes/bag; 18 bags/case

TuffStuff™ Light Duty Wipes

TuffStuff light duty wipes are ideal for light cleaning tasks. These general purpose wipes are thick, strong and highly absorbent. They are made of sorbent cellulose and reinforced with polyester. Available in a roll and quarterfolded, these light duty wipes are packaged to meet a wide variety of customer needs.

Applications:

- Routine cleaning tasks
- Light duty maintenance tasks
- Applying solvents, cleaners and lubricants
- Sorbing spills
- Soft for face and hand wiping

Construction:

- Thick cellulose construction to maximize sorbency
- Reinforced with polyester to provide wet strength
- Hydroentangled with no binders or additives
- Available in white



Part No.	Description	Quantity
Light Duty Creped White		
TSWS1014	TuffStuff Light Duty, cellulose/polyester wipes, white, perforated roll, 9.5" x 13.5" (24 x 34cm)	500 wipes/roll
TSWS1213	TuffStuff Light Duty, cellulose /polyester wipes, white, quarterfolded, 12" x 13" (30 x 33cm)	50 wipes/bag; 10 bags/case



Contec® cleaning and disinfecting products are available throughout the world. Sales representatives are conveniently located across Europe, Asia and North and South America. Please visit www.contecinc.com to find a sales representative in your area and to learn more about our products for critical environments.

Presaturated Wipes
Mopping Systems
Disinfectants

Spill Control Products
Knitted Wipes
Sterile Products

Sponges
Nonwoven Wipes
Swabs

Visit our website for more information: www.contecinc.com.

Copyright © 2018 Contec, Inc. All rights reserved. WIP034 020218

Contec, Inc
Spartanburg, SC
United States
Tel: +1 (864) 503-8333

Contec
Vannes Cedex
France
Tel: +33(0) 2 97 43 76 98

Contec Cleanroom Technology (Suzhou) Co. Ltd
Suzhou
China
Tel: +86-512-6274 4050

