

# Textured Edgeless<sup>®</sup> Mop

## 13oz Textured polyester knitted tube mop

The Textured Edgeless Mop is made of strong, durable 100% polyester knitted fabric looped to form continuous strands that will not shed or break. Unique ribbed, patented, twisted mop strands provide excellent sorbency. The textured headband assists in tough cleaning tasks.

Designed for use with aqueous solutions containing cleaning agents and disinfectants, Edgeless Mops are compatible with a wide range of chemicals. These mops work well with existing string mop hardware; however, we highly recommend a down-press wringer for proper liquid extraction.

Mops are laundered and packaged in an ISO Class 4 cleanroom. Available validated sterile per AAMI Guidelines.

Designed for semiconductor, pharmaceutical, biotech and medical device industries for lab and process area cleaning. Recommended autoclave cycle is 121 °C for 30 minutes.

Available sterile.



### Features & Benefits

- Durable and chemical resistant
- Continuous loop of mop strands provides improved cleanliness, eliminating cut edges
- Textured large head band provides scrubbing power for difficult stains and debris

### Performance Characteristics

#### Product Information

Mop head materials	100% polyester
ISO Class	4-8
cGMP Grade	A/B - for sterile version, C/D - for non-sterile version
Compatible Mop Frames	2646F, A71612
Shelf Life	For Sterile Products: 2 years from manufacturing date

See other side for additional information.

Copyright © 2019 Contec, Inc. All rights reserved. ETR3397 062519

## Technical Data

Attribute (units)	Typical Value*	Test Method**
Mop weight, dry; oz (g)	13 (369)	CTM004-03
Sorbent capacity; (mL/mop)	1819	CTM004-03

- \*Notes
- a) The data shown are typical values and should not be used as product specifications.
  - b) Valid product comparisons may only be obtained through side-by-side testing in the same test facility, under similar conditions.
  - c) Current and/or comparison data may be available. Please contact a Contec sales representative for details.

- \*\*Test Methods:
- 1) CTM – Refers to Contec Test Method
  - 2) IEST-RP-CC004.3, Evaluating Wiping Materials Used in Cleanroom and Other Controlled Environments, Institute of environmental Sciences and Technology, Rolling Meadows IL.

## Products

Part Number	Description	EA/OB1	OB1/OB2	OB2/CS	EA/CS
ELMOP3	Textured Edgeless Mop, 23.25" x 21" x 16" (59 x 53.3 x 40.6cm), 13oz	1	1	30	30
ELMOP3IR	Textured Edgeless Mop, 23.25" x 21" x 16" (59 x 53.3 x 40.6cm), 13oz, sterile	1	1	30	30

## Additional Information

For Sterile products, Certificates of Conformance and Sterility are available at [www.contecinc.com/Resources/Certificate Search](http://www.contecinc.com/Resources/Certificate%20Search)  
 Products are Validated Sterile by Gamma irradiation to a Sterility Assurance Level of 10<sup>-6</sup> according to AAMI Guidelines  
 Contec holds ISO 9001:2015 registration. Additional Product information available at [www.contecinc.com](http://www.contecinc.com).