

Contec® Professional Guide to Proper Mopping

How to Saturate and Clean with Premira® Mop Pads:



1. Remove the paper band around the bundle of 20 Premira® mop pads (PRMM0001)
2. Place the mops in the bucket, printed side up.



1. Fill 3 quart bottles with the appropriate chemical (neutral floor cleaner).
2. Pour both quart bottles evenly over the entire bundle to evenly saturate the mop pads.
3. Keep an extra quart bottle of chemical on your cart and add chemical as needed.



1. Adjust the height of your mop handle.
2. Open cam-lock, extend to desired height, close cam-lock.
3. The ideal handle height is just below chin level.



1. Attach the handle to the blue mop frame by lining up the two prongs on the frame with the Z-clip on the handle.
2. Press the handle down firmly onto the frame until you hear a "click".



1. Lay the saturated mop pad out on the floor with the printed side up.
2. Line the frame up flush on one short mop edge, leaving a 1-inch lip on the other side of the frame.
3. Start mopping from the back of the room to the front and use "S-motion" so the same edge is always leading.



1. To remove the used mop, simply pull soiled pad up from bottom of frame to fold in half.
2. Once it's folded in half, pull it down to middle of the frame and remove.
3. This technique makes sure that all contaminants are contained inside the used mop and aren't spread back into the room.

DISCLAIMER: The following document is intended to serve as a tool to provide documentation of competency only and is in no way providing certification of the information in this document. Facilities should follow their own guidelines, policies and procedures which, in all cases, will take precedence over this training document.