

# Contec Mop Head Saturation System

Designed to simplify the cleanroom mopping process, Contec's Mop Head Saturation System allows mop heads to be presaturated prior to being passed into the controlled environment. This eliminates the need for any water to be passed into the cleanroom.

Small and compact, the stainless steel cart with twin 8L buckets is ideal for small to medium sized cleanroom. Being lightweight and manoeuvrable the cart is easy to use. The cart is fitted with four non marking, autoclavable castors, meaning the whole cart can be autoclaved before use.

In order to make the system highly efficient and cost effective the mop heads used need to be fast-wicking and highly sorbent. Contec has developed a new flat mop head to be used as part of the system; Contec Quiltec I Polyester Mop Heads.

The buckets are designed to take 5 flat mop heads which can be saturated with 1L of fluid. The second bucket can be used for the dilution of a concentrate and then to store the used mop heads preventing any cross contamination.

The mop heads are placed on an easy-fit mop applicator frame which coupled with the mop head design, means the mop heads can be fitted to the mop frame hands-free. A stainless steel disinfectant diffuser tray helps to evenly saturate every mop head. The diffuser tray can be placed into a slot on the side of the cart when not in use for easy storage. Simply pour the disinfectant onto the mop heads either from the bottle or straight from the other bucket, wait 5 mins for full saturation and the mops are ready to use.

Contec Quiltec I Mop Heads are manufactured from 100% 2-ply polyester around a polyester / rayon core so are ideal for even the highest grade of cleanroom as they generate very small numbers of particle and fibres.



FEATURES	BENEFITS
100% 2-ply polyester covered mop heads	<ul style="list-style-type: none"> <li>• Low levels of particle and fibres</li> <li>• Highly sorbent providing good coverage for each mop</li> <li>• Excellent surface contact</li> </ul>
Hands free mop application	<ul style="list-style-type: none"> <li>• Easy and convenient to use</li> </ul>
Presaturated mop heads	<ul style="list-style-type: none"> <li>• Eliminates the need for a heavy or expensive wringer system</li> <li>• No water needs to be taken into the cleanroom</li> </ul>
Stainless steel with polypropylene castors	<ul style="list-style-type: none"> <li>• Suitable for autoclaving at 121° C for 30 mins</li> <li>• Compatible with a wide range of disinfectants and detergents</li> </ul>
Compact system	<ul style="list-style-type: none"> <li>• Requires only a small storage area</li> </ul>
Twin buckets	<ul style="list-style-type: none"> <li>• No risk of cross contamination</li> <li>• Allows mixing of concentrates if required</li> <li>• Allows easy removal and disposal of used mop heads</li> </ul>

For more information or to request a sample, e-mail [infoeu@contecinc.com](mailto:infoeu@contecinc.com) or phone + 33 (0) 2 97 43 76 98.

Copyright © 2019 Contec, Inc. All rights reserved. INT113 250919

Contec  
Vannes Cedex  
France  
Tel: +33(0) 2 97 43 76 98

Contec Inc  
Spartanburg, SC  
United States  
Tel: +1 (864) 503-8333

Contec Cleanroom Technology (Suzhou) Co. Ltd  
Suzhou  
China  
Tel: +86-512-6274 4050



## Product Specification

### Mop Head Saturation Cart

- Stainless steel castor base with 4 polypropylene copolymer castors
- 2 x 8L stainless steel buckets with handles
- Stainless steel disinfectant diffuser tray
- Stainless steel easy-fit mop head applicator frame
- Complete system measures 51cm (L) x 30cm (W) x 25cm (H)



### Quiltec I Mop Heads

- Two-ply 100% knitted polyester over a polyester / rayon core
- Gamma irradiated at no less than 25kGy
- 5 mops double bagged
- Approx 18 - 20 sqm coverage
- Certificates of conformity supplied with every batch

Part No.	Description	Size	Packaging
2787	Contec Mop Head Saturation System	51 x 30cm	Each
2749	QuickTask Mop Frame Stainless steel flat mop frame	39 x 10cm	Each
2643	QuickConnect Extendable Handle Anodised aluminium telescopic handle	130 – 230cm	Each
2645	QuickConnect Extendable Handle Stainless steel telescopic handle	130 – 230cm	Each
2725E	QuickConnect Handle Stainless steel one piece handle	150cm	Each
MHQT0100	Quiltec I Mop Head Polyester quilted mop head	39 x 13cm	5 per bag; 8 bags per case
MHQT0150	Sterile Quiltec I Mop Head Polyester quilted mop head	39 x 13cm	5 per bag; 8 bags per case