

Knitted Looped Microfibre polyester Mop head

100% knitted cleanroom laundered microfibre polyester

The QuickTask mopping range consists of a variety of flat mop heads that can be easily attached to a choice of flat mop head frame and handle assemblies.

The TASK0400 mop is manufactured from 100% knitted microfibre polyester which has been cleanroom laundered making it the cleanest mop in the range with extremely low levels of particulates.

The tubular knit loops making cleaning of cove bases and ceiling/wall joints easier than with standard flat mops. The looped construction is very sorbent, suitable for mopping-to-dry already wet surfaces.

The mop heads are compatible with a wide range of chemicals and disinfectants, including chlorine solutions. With appropriate validation, the mops can be laundered and autoclaved, providing exceptional value.

The heads are compatible with the QuickTask Magnetic Mop Head Frames 2906 and 2699, and the QuickTask Polypropylene Mop Frame 2740.



Features	Benefits
Cleanroom laundered 100% polyester	<ul style="list-style-type: none"> • Very low levels of particle and fibres • Compatible with a wide range of disinfectants and detergents • Highly durable
Knitted tubular loops	<ul style="list-style-type: none"> • Highly sorbent so saves time as reduces number of visits back to a bucket system • Ideal for mop-to-dry performance on wet surfaces
Suitable for hands free mop removal *	<ul style="list-style-type: none"> • Easy and convenient to use • Reduces cross contamination

* with appropriate hardware

Part No.	Description	Size	Packaging
TASK0400	Knitted looped microfibre polyester mop heads	41 x 13 cm	10 mops per bag 5 bags per case

Copyright © 2023 Contec, Inc. All rights reserved. INT266 280423

