



# TuffStuff™

## Critical Task Wipes for Various Environments

TuffStuff Wipes are high quality critical task wipes. Available in Light, Medium and Heavy Duty, these wipes are solvent resistant and maintain their strength even when wet.

TuffStuff wipes offer exceptional durability and cleanliness making them ideal for critical cleaning in biotech and pharmaceutical industries as well as equipment and production line maintenance.

TuffStuff Wipes are available in multiple sizes, weights, and packaging configurations to meet the various customer needs.

The expanded range includes TuffSat, consisting of heavy duty dry wipes, quarterfolded in a tub that can be saturated with cleaning solution. This versatile option allows wipes to be customised with the correct cleaning solution for that particular environment.



FEATURES	BENEFITS
Hydroentangled nonwoven wipes	<ul style="list-style-type: none"> <li>• Provide strong, durable wipes without the use of binders</li> <li>• Highly sorbent without the use of surfactants</li> <li>• Low linting</li> </ul>
Light, medium and heavy duty wipes available	<ul style="list-style-type: none"> <li>• Allows user to match the ideal wipe for the specific application</li> </ul>
Various packaging configurations	<ul style="list-style-type: none"> <li>• Choice of pop-up, perforated rolls and quarterfolded wipes</li> </ul>
Multiple wipe sizes	<ul style="list-style-type: none"> <li>• Various wipes sizes allow optimum selection for each job</li> </ul>
Performance and strength	<ul style="list-style-type: none"> <li>• Ideal for general cleaning applications or applying solvents</li> <li>• Offers strength wet or dry, no residues or binders left behind</li> </ul>

Category	Strength	Abrasion Resistance	Thickness	Absorption Capacity
Light Duty	• •	• •	• • • • •	• • • •
Medium Duty	• • •	• • •	• • •	• • •
Heavy Duty	• • • • •	• • •	• • •	• • •

For more information or to request a sample, email [infoeu@contecinc.com](mailto:infoeu@contecinc.com) or phone + 33 (0) 2 97 43 76 98.

Copyright © 2020 Contec, Inc. All rights reserved. INT106 280220

# TuffStuff™ Heavy Duty Wipes

TuffStuff heavy duty wipes are ideal for tough cleaning and maintenance tasks. These wipes offer an excellent combination of sorbency and durability. They are very strong wet or dry and are ideal for heavy duty cleaning with disinfectants or detergents.



## Applications:

- Tough cleaning and maintenance tasks, such as cleaning rough surfaces and scrubbing
- Process equipment maintenance and cleaning
- Cleaning and wiping down parts, equipment and machinery
- Surface preparation with solvents
- Low lint glass cleaning

## Construction:

- Cellulose for superior sorbency, reinforced with polyester for superior strength
- Hydroentangled for cleanliness and durability
- Very strong wet or dry
- No binders or adhesives
- Creped to provide soft feel
- Available in white or blue

Part No.	Description	Quantity
<b>Heavy Duty Creped White</b>		
TSWC0917	TuffStuff Heavy Duty, cellulose/polyester wipes, creped white, pop-up dispenser box, 23 x 42cm	100 wipes/box; 8 boxes/case
TSWC1214	TuffStuff Heavy Duty, cellulose/polyester wipes, creped white, roll-in dispenser box, 30 x 33cm	500 wipes/roll
TSWC1217	TuffStuff Heavy Duty, cellulose/polyester wipes, creped white, double pop-up dispenser box, 30 x 42cm	125 wipes/box; 2 boxes/case
C1C1217Q	TuffStuff Heavy Duty, cellulose/polyester wipes, creped white, quarterfolded, 30 x 42cm	500 wipes/bag; 2 bags/case
<b>Heavy-Duty Creped Blue</b>		
TSBC1213	TuffStuff Heavy Duty, cellulose/polyester wipes, creped blue, quarterfolded, 30 x 33cm	50 wipes/bag; 10 bags/case

# TuffSat

In addition to the dry TuffStuff range, TuffSat provides large heavy duty textured wipes that are quarterfolded and in a tub ready to be presaturated with a cleaning solution. This is ideal for customers looking to eliminate spray bottles. The tub keeps the wipes saturated for extended periods of time and can be reused.

**Not recommended for highly evaporative solvents.**

## Application:

- Cleaning of surfaces with detergents or cleaning solutions
- Tough cleaning tasks that benefit from a textured wipe or require a scrubbing wipe to enhance cleanability.

## Construction:

- Textured fabric
- Thick and highly sorbent
- Large quarterfolded wipes
- No binders or surfactants that can contaminate surfaces



Part No.	Description	Quantity
<b>TuffSat</b>		
TSWT1217	TuffStuff Heavy Duty, cellulose/polyester wipes, textured white, quarterfolded, 30 x 43cm	50 wipes/bag; 18 bags/case
TSCN0001	TuffSat Dispenser Tub	4 each/case

# TuffStuff™ Medium Duty Wipes

For moderate cleaning and maintenance tasks, TuffStuff medium duty wipes offer excellent strength and absorption. Medium duty wipes have good strength wet or dry. They are bulky, durable and can stand up to many cleaning tasks.

## Applications:

- General maintenance and industrial jobs
- Cleaning up soil, oils, grime, solvents and lubricants
- Wiping surfaces and tools
- Applying solvents and thinners
- General glass cleaning

## Construction:

- Medium weight with a good balance of cellulose and polyester
- Provides a good combination of sorbency and strength
- Hydroentangled for durability and cleanliness
- Contains no binders or adhesives
- Creped to provide soft feel
- Available in white



Part No.	Description	Quantity
<b>Medium Duty Creped White</b>		
TSWL1213	TuffStuff Medium Duty, cellulose/polyester wipes, creped white, quarterfolded, 30 x 33cm	50 wipes/bag; 18 bags/case
TSWL1217	TuffStuff Medium Duty, cellulose/polyester wipes, creped white, quarterfolded, 30 x 42cm	50 wipes/bag; 18 bags/case

# TuffStuff™ Light Duty Wipes

TuffStuff light duty wipes are ideal for light cleaning tasks. These general purpose wipes are thick, strong and highly absorbent. They are made of sorbent cellulose and reinforced with polyester. Available in a roll and quarterfolded, these light duty wipes are packaged to meet a wide variety of customer needs.

## Applications:

- Routine cleaning tasks
- Light duty maintenance tasks
- Applying solvents, cleaners and lubricants
- Sorbing spills
- Soft for face and hand wiping

## Construction:

- Thick cellulose construction to maximize sorbency
- Reinforced with polyester to provide wet strength
- Hydroentangled with no binders or additives
- Available in white



Part No.	Description	Quantity
<b>Light Duty Creped White</b>		
TSWS1014	TuffStuff Light Duty, cellulose/polyester wipes, white, perforated roll, 24 x 34cm	500 wipes/roll
TSWS1213	TuffStuff Light Duty, cellulose /polyester wipes, white, quarterfolded, 30 x 33cm	50 wipes/bag; 10 bags/case



Contec® cleaning and disinfecting products are available throughout the world. Sales representatives are conveniently located across Europe, Asia and North and South America.

Please visit [www.contecinc.com/eu](http://www.contecinc.com/eu) to find a sales representative in your area and to learn more about our products for critical environments.

Presaturated Wipes  
Mopping Systems  
Disinfectants

Spill Control Products  
Knitted Wipes  
Sterile Products

Sponges  
Nonwoven Wipes  
Swabs

*For more information or to request a sample, email [infoeu@contecinc.com](mailto:infoeu@contecinc.com) or phone + 33 (0) 2 97 43 76 98.*