Contec[®] MicroCinch[™] Mop

Disposable microfiber pads for efficient pharmacy cleaning and disinfecting

The USP <797> compliant, disposable Contec® MicroCinch™ Mop is constructed of 100% synthetic microfiber that provides superior removal of gross soil and fine particulate. Reduces cross-contamination associated with reprocessed mops, and is suitable for ISO Class 7 and 8 environments. Compatible with most common disinfectant chemistries including quaternary, alcohol, peroxide, and bleach-based disinfectants, the low-lint flat mop can be used wet or dry, and the pad provides uniform surface coverage and liquid distribution.

The "pocket" style design allows for quick changing of mop pads and the autoclavable, collapsible mop frame, available in heavy-duty plastic or stainless steel, easily snaps into the pad pockets. Contec's MicroCinch Mop is the ideal solution for daily cleaning and disinfecting of Secondary Engineering Controls required in pharmacy environments. Cleanroom packaged for guaranteed quality and cost effectiveness. Available gamma irradiated. Validated sterile to a Sterility Assurance Level of 10⁻⁶ per AAMI ISO 11137 Guidelines.



Pocket design allows for quick attachment to hardware, making the Contec MicroCinch Mop a better alternative for efficient, quick cleaning. See part details for heavyweight construction.

| Features | Benefits | | |
|---|---|--|--|
| Constructed of 100% synthetic microfiber | Compatible with most common disinfectant chemistries Eliminates phenomenon known as "quat binding" where disinfectant solutions are rendered ineffective by organic materials found in some mop constructions and reprocessed mops | | |
| Disposable mop pad | Eliminates cross contamination from laundries, lint and organic material in cotton and rayon mops Eliminates potential chemistry reactions from relaundered or reprocessed mops | | |
| Low-lint construction | • Microfiber material is excellent for removing gross soil and fine particulate from cleanroom floors | | |
| Appropriate cleanroom packaging | Reduces chance for or introduction of contamination Conveniently packaged for appropriate daily/weekly mopping needs | | |
| USP <797> compliant • Compatible with ISO Class 7 and 8 environments | | | |

MOP023 | 101023

Copyright © 2023 Contec, Inc. All rights reserved.



| Part no. | Description | | Size | Packaging |
|----------|---|-----------|--------------------------------|---------------------|
| HCPM5001 | Contec MicroCinch Mop cover with pockets, standard weight | | 5" x 15.5" (12.7 x 39.3 cm) | 8/bag; 15 bags/case |
| HCPM5051 | Contec Sterile MicroCinch Mop cover with pockets, standard weight | Sterile) | 5" x 15.5" (12.7 x 39.3 cm) | 2/bag; 35 bags/case |
| 2740 | MicroCinch flat-hinged mop frame Blue polypropylene | | 16" x 4.25" (41 x 11 cm) | 1/case |
| HCPH8007 | MicroCinch flat-hinged mop frame Stainless steel | | 16" x 4.25" (40 x 10.8 cm) | 1/case |
| 2906 | MicroCinch magnetic mop frame, Stainless steel | | 15.5" x 3.75" (40 x 10 cm) | 1/case |
| 2725E | QuickConnect [™] Handle Stainless steel | | 60" (152 cm) | 1/case |







2740 2906 2725E