

# Contec® CritiGear™ Cleanroom Frocks

## Cleanroom frocks for USP <797> environments

Contec’s CritiGear™ Frocks have been specifically designed to meet the needs of USP <797> compounding cleanroom environments. The ISO Class 7 cleanroom compatible frocks feature microporous fabric technology that protects the sensitive cleanroom environment found in the pharmacy, yet are comfortable for the wearer. The microporous fabric is low-lint, low in particulate, and is antistatic to improve donning and user comfort. CritiGear Frocks are an excellent particulate barrier, are liquid repellent, and wick body moisture away to provide better comfort. Suitable for users in sterile compounding pharmacies, research, and pharmaceutical manufacturing, the CritiGear Frocks have been designed with cleanroom environments in mind.

The extra long, knee-length frocks protect the compounding environment from the number one source of contamination found in cleanrooms—people. The mandarin collar and the six snap front provide proper closure from the neck down to better control particulate contamination generated by the wearer. The unique knit cuffs with thumb loops make donning sterile gloves easier and prevent exposed wrists and forearms during compounding. Available in sizes X-Small to 5X-Large.



Designed for compounding pharmacies, laboratories, cleanrooms, and other environments where fiber and particulate contamination is a concern.

Features	Benefits
Microporous Fabric	<ul style="list-style-type: none"> <li>• Low-lint, low particulate, excellent particulate barrier</li> <li>• Provides excellent moisture vapor transmission making frock cooler to wear</li> <li>• Fluid resistant</li> <li>• Antistatic treated for easy donning and increased comfort</li> <li>• Latex-free and Nitrile-free</li> </ul>
Thumb Loop	<ul style="list-style-type: none"> <li>• Greatly enhances sterile glove donning by preventing the sleeve from sliding up during donning process</li> </ul>
Knit Cuff	<ul style="list-style-type: none"> <li>• Provides tapered fit which improves sterile glove donning and user comfort</li> </ul>
Knee-length	<ul style="list-style-type: none"> <li>• Directs contaminants generated from wearer away from critical sites to areas well below work surface</li> </ul>
Mandarin Collar	<ul style="list-style-type: none"> <li>• Provides more complete closure, eliminating the problems associated with lapel style collars</li> </ul>

Part no.	Description	Size	Packaging
HCGA0002	CritiGear Cleanroom Frock	X-Small	10/bag, 3 bags/case
HCGA0012	CritiGear Cleanroom Frock	Small	10/bag, 3 bags/case
HCGA0022	CritiGear Cleanroom Frock	Medium	10/bag, 3 bags/case
HCGA0032	CritiGear Cleanroom Frock	Large	10/bag, 3 bags/case
HCGA0042	CritiGear Cleanroom Frock	X-Large	10/bag, 3 bags/case
HCGA0052	CritiGear Cleanroom Frock	2X-Large	10/bag, 3 bags/case
HCGA0062	CritiGear Cleanroom Frock	3X-Large	10/bag, 3 bags/case
HCGA0072	CritiGear Cleanroom Frock	4X-Large	10/bag, 3 bags/case
HCGA0082	CritiGear Cleanroom Frock	5X-Large	10/bag, 3 bags/case

Note: Additional sizes may be available. Contact your Contec Healthcare sales representative for details and lead times.