

Klean Max™ Wall Washing System

Disposable polyester and microfiber mop head for cleaning and disinfecting

Designed for cleaning and applying disinfectants to both horizontal and vertical surfaces in pharmacy cleanrooms and other critical healthcare environments, lightweight Klean Max has a slim profile and is ideal for general cleaning of ceilings, walls, and floors. The pivoting mop head frame makes it easy to clean around door and window frames as well as light fixtures and heavy equipment.

Intended for limited-use, the 100% synthetic polyester and microfiber Klean Max mop does not promote bacteria growth, reducing the risk of cross contamination, leading to better patient outcomes. The unique construction allows for even application of disinfectants and cleaning solutions. The slightly textured microfiber face provides superior particle pick up and contamination removal.

Available in three lengths, 8.4" (21cm), 12.8" (32.4cm), and 15" (38cm), the larger Klean Max is ideal for cleaning and disinfecting broad surfaces in pharmacy cleanrooms. The small and medium-sized (also available with a sealed edge)-Klean Max is appropriate for tasks in smaller environments. Ergonomic, lightweight adjustable handles are available in several lengths for maximum flexibility. All hardware is autoclavable.



Ideal for use on floors, walls, and ceilings found in USP <797> and USP <800> regulated pharmacy cleanroom facilities, Contec® Klean Max™ Mop helps to ensure compliance and meet stringent cleaning and disinfecting protocols.

Features	Benefits
Mop Head	Mop Head Frames, Handles and Buckets
Klean Max enables the uniform application of disinfectants and cleaning solutions. Compatible with a wide range of solutions, including bleach* and hydrogen peroxide, Klean Max also does not interfere with the efficacy of quat-based disinfectants.	The disposable Klean Max mop head installs easily onto the appropriate sized mop head frame and QuickConnect™ handle. Frames 2652LF, lay flat for cleaning under or behind equipment.
Inherently clean polyester and urethane mop head does not harbor bacteria, reducing the risk of spreading organisms that cause infections.	QuickConnect handles are autoclavable and available in several lengths for a variety of cleaning tasks.
Hydrophilic urethane and knitted polyester mop head retains liquids better than competitive products. When the mop is applied to a surface, liquid is evenly released without dripping.	Contec offers single, double and triple bucket systems to complement Klean Max mops. Choose from stainless steel or autoclavable polypropylene. Visit our web site for details.
Klean Max is non-shedding. Laser cutting seals the edges of the urethane and polyester, reducing the chance of fiber and particle contamination.	
Available Gamma irradiated. Validated sterile to a Sterility Assurance Level of 10 ⁻⁶ per AAMI ISO11137:2006 Guidelines.	

For additional cleaning and scrubbing power, we recommend adding microfiber wipes to our Klean Max System. Wipes can be used dry, slightly damp or fully charged with disinfectant, depending upon the application.

*Klean Max is disposable and designed for limited use. If left in bleach solution over a 24-hour period, the mop head will discolor.

2652LF,
HCKM3004, 2725E



Ribbed microfiber face with sealed edge.

features

Klean Max™ Mop Head Sealed Edge

- Thermally sealed edges that increase durability and eliminate the chance of fiber and particle contamination
- Excellent chemical and abrasion resistance; lasts longer than traditional sponge mops
- Available gamma irradiated and validated sterile to a Sterility Assurance Level of 10^{-6} per AAMI ISO11137 Guidelines

NOTE: Autoclaving of Klean Max Sealed Edge is not recommended, due to the thermoformed plastic backplate.

Part No.	Description	Packaging
Mop Heads		
HCKM3001	Klean Max mop head, small, 8 x 4 x 1" (20x10x2cm)	4 each/bag; 12 bags/case
HCKM3051	Klean Max mop head, small, sterile, 8 x 4 x 1" (20x10x2cm)	1 each/bag; 48 bags/case
HCKM3002	Klean Max mop head, medium, 13 x 4 x 1" (33x10x2cm)	4 each/bag; 7 bags/case
HCKM3052	Klean Max mop head, medium, sterile, 13 x 4 x 1" (33x10x2cm)	1 each/bag; 28 bags/case
HCKM3003	Klean Max mop head, large, 15 x 4 x 1" (38x10x2cm)	4 each/bag; 6 bags/case
HCKM3053	Klean Max mop head, large, sterile, 15 x 4 x 1" (38x10x2cm)	1 each/bag; 24 bags/case
HCKM3005	Klean Max mop head, small, sealed edge, 9.5 x 5 x .0375" (24x13x1cm)	4 each/bag, 10 bags/case
HCKM3055	Klean Max mop head, small, sealed edge, sterile, 9.5 x 5 x 0.375" (24x13x1cm)	1 each/bag, 40 bags/case
HCKM3004	Klean Max mop head, medium, sealed edge, 15 x 5 x 0.375" (38x13x1cm)	4 each/bag, 4 bags/case
HCKM3054	Klean Max mop head, medium, sealed edge, sterile, 15 x 5 x 0.375" (38x13x1cm)	1 each/bag, 24 bags/case
Mop Head Frames and Handles		
2651SS	QuickConnect™ mop head frame, 7.5" (19cm), stainless steel, for small mop heads	1/each
2652LF	QuickConnect™ mop head frame, 11.5" (29cm), stainless steel, for medium & large mop heads	1/each
2725E	QuickConnect handle, 60" (152.4cm), stainless steel, lightweight, 1 piece	1/each
2642	QuickConnect handle, 16" (40cm) extends to 30" (76cm), anodized aluminum	1/each
2643	QuickConnect handle, 50" (127cm) extends to 92" (234cm), anodized aluminum	1/each
2644	QuickConnect handle, 16" (40cm) extends to 30" (76cm), stainless steel	1/each
2645	QuickConnect handle, 50" (127cm) extends to 92" (234cm), stainless steel	1/each

NOTE: Due to thermoforming of the plastic backplate, autoclaving of Klean Max is not recommended. All hardware is autoclavable unless otherwise noted.

