

Contec® Healthcare Low-Lint Hand Drying Wipes

Absorbent, disposable, low-lint wipe for hand drying

Proper hand hygiene during garbing and selection of the appropriate consumables are critical to maintain the state-of-control when entering a sterile compounding environment. Contec Healthcare has developed a solution for drying hands and forearms with our newly introduced USP <797> compliant low-lint hand drying disposable wipes.

These large, absorbent 17" x 9" (43 x 23 cm) low-lint wipes packaged in easy to open plastic bags, dispense from our 9451 stainless steel wall mountable dispensers. This new dispenser and packaging for the low-lint wipes eliminate the struggle to grab one wipe off the top of a stack of traditional cleanroom wipes. The bottom-pull design prevents dripping water from the hands contaminating other wipes. Thus avoiding contamination concerns and potential for wetting subsequent wipes often associated with 12" x 12" (30.5 x 30.5 cm) wipes in flat stacked configurations.

The bags of wipes can easily be wiped when introducing the product to the clean side of the anteroom. In addition, when the wipes are left in the bag, wipe stacks will remain neatly configured to provide lot traceability.

Contec Healthcare Low-Lint Hand Drying wipes are compliant with USP Chapter <797>.



Large absorbent 17" x 9" low-lint wipes are compliant with USP<797>

Features	Benefits
USP<797> compliant	<ul style="list-style-type: none"> Low-lint disposable wipes are compliant with 2008 and the 2019 revision to USP Chapter <797>
Large 17" x 9" (43 x 23 cm) low-lint absorbent wipes	<ul style="list-style-type: none"> Absorbent, disposable hand and elbow drying wipe Use one wipe to complete task vs. 9" x 9" (23 x 23 cm) or 12" x 12" (30.5 x 30.5 cm) wipes
Wall-mounted stainless steel dispenser	<ul style="list-style-type: none"> Downward dispenser is engineered to minimize contamination (e.g., avoid splashing from sink and dripping from hands) Other dispensing alternatives can be open to the environment and do not protect wipes from contamination
Packaged wipes	<ul style="list-style-type: none"> Protects against potential contaminants and gets stacks organized for ease in dispensing Packaging minimizes the risk of airborne contamination. The bags of wipes can be easily wiped down with a sporicidal, EPA-registered disinfectant, or sterile 70% IPA when taken into the clean side of anteroom

Part no.	Description	Size	Packaging
HCC20001	Absorbent, disposable, low-lint wipe for hand drying wipe	17" x 9" (43 x 23 cm)	100/bag, 9 bags/case
9451	Hand wipe dispenser Stainless steel	10" x 4.75" x 9" (25.4 x 12.07 x 23 cm)	1/case

WIP040 | 061323

Copyright © 2023 Contec, Inc. All rights reserved.