



TuffStuff™ Heavy Duty Wipes

Critical Task Wipes, Creped White

Description

TuffStuff heavy duty nonwoven wipes are made from polyester/cellulose fabric. These nonwoven wipes are hydroentangled for durability and cleanliness. They contain no binders or adhesives and are considered low lint. They offer excellent absorption, have good strength when wet or dry and can stand up to many cleaning tasks. Creped for softness and sorbency.

Ideal for tough cleaning and maintenance tasks, TuffStuff heavy duty wipes are excellent for cleaning up soil, oils, grime, solvents and lubricants, as well as applying solvents and thinners. They are very effective in applications such as surface preparations for coatings, machine operations and general maintenance.

TuffStuff heavy duty wipes are available quarterfolded, pop-up, and dispensing roll configurations.

Technical Data

Attribute; (units)	Value **	Test Method
Basis weight; (g/m ²)	65	
Sorbency in water		
Intrinsic; (mL/g)	5.5	IEST-RP-CC004.3, Sec. 8.1
Extrinsic; (mL/m ²)	329	IEST-RP-CC004.3, Sec. 8.1
Sorptive rate, (seconds)	< 1	
Non-volatile residue, NVR		IEST-RP-CC004.3, Sec. 7.1.2
In deionized water; (g/m ²)	0.01	
In isopropanol; (g/m ²)	0.01	

Part Number	Description	EA/OB1	OB1/CS	EA/CS
C1C1217Q	TuffStuff Creped White Wipes, 12" x 17" (30 x 42cm), quarterfolded	500	2	1000
TSWC1217	TuffStuff Creped White Wipes, 12" x 16.5" (30 X 42cm), quarterfolded	125	2	250

Part Number	Description	EA/BX	BX/CS	EA/CS
TSWC0917	TuffStuff Creped White Wipes, 9" x 16.5" (23 x 42cm), pop-up box	100	8	800

Part Number	Description	EA/RL	RL/CS
TSWC1214	TuffStuff Creped White Wipes, 12" x 13" (30 x 33cm), roll in dispenser box	500	1

Key: EA = Each, OB1 = Outer Bag 1, OB2 = Outer Bag 2, RL = Roll, CS = Ca

Notes:

- 1) The information presented here is applicable to the part numbers shown above as well as to any product containing the same materials and produced under the same conditions, regardless of product size or packaging configuration. Please contact a Contec sales representative for more details.
- 2) Data shown are typical values and should not be used as product specifications.
- 3) Valid product comparisons may only be obtained through side-by-side testing in the same test facility, under similar conditions.
- 4) Current and/or comparison data may be available. Please contact a Contec sales representative for details.

Revision date: 2/20/2018
ETR 3523



Copyright © 2018 Contec, Inc. All rights reserved.

North America
P.O. Box 530
Spartanburg, SC 29304 USA
Phone: +1-864-503-8333
www.contecinc.com

Europe
Zl du Prat – RP 3707
56037 VANNES Cedex
FRANCE
+33 297 437 698

China
No.17 Longyun Road
Suzhou 215024
CHINA
+ 86-512-6274 4050