

CleanTube™ Wipes

100% polyester knit tubular wipes

CleanTube™ wipes bring the cleanliness of controlled environment laundering to the automotive industry. Made of 100% polyester, this durable fabric provides excellent sorbency while the knit construction produces a high-stretch quality that allows for ease of cleaning in tight spaces. CleanTube wipes are available in a variety of lengths, textures, and quantities, making them ideal for a variety of surface preparation applications.

The unique tubular shape of the wipes allows technicians to “load” their arms with several wipes at a time to diminish downtime, and the heat-sealed edges naturally roll outward to reduce the potential for particle contamination from cut fibers. Originally designed for removing excess sealant, these low-linting wipes are also excellent for cleaning paint automation equipment.



Product Information		Benefits	
Material	100% polyester		
Construction	Knit		
Attributes (units)	Typical Value*	Test Method	
Basis weight (oz/yd ²)	4.5		
Sorptive rate (seconds)	25		
Non-volatile residue, NVR IPA (g/m ²)	0.065		
Particles, readily releasable P ≥ 3.0µm (x10 ⁶ /m ²)	1.36	IEST-RP-CC004.2, Sec. 5.1	
Fibers > 100µm (x10 ³ /m ²)	0.0325	IEST-RP-CC004.2, Sec. 5.2	

Part no.	Description	Size	Packaging
LWTW7L10	CleanTube Wipes Tubular lacoste ribbed knit	7" x 10" (178 x 250 mm)	100/bag; 5 bags/case
LWTW0016	CleanTube Wipes Tubular lacoste ribbed knit	10" x 12" (250 x 305 mm)	100/bag; 5 bags/case
LWTW0030	CleanTube Wipes Tubular lacoste ribbed knit	10" x 14.5" (250 x 368 mm)	78/bag; 5 bags/case
LWTW7J10	CleanTube Wipes Tubular jersey smooth knit	7" x 10" (178 x 250 mm)	100/bag; 5 bags/case
LWTW0036	CleanTube Wipes Tubular jersey smooth knit	9" x 10" (230 x 250 mm)	100/bag; 5 bags/case
LWTW0031	CleanTube Wipes Tubular jersey smooth knit	9" x 24" (230 x 609 mm)	53/bag; 5 bags/case
LWTW0025	CleanTube Wipes Tubular lacoste ribbed	4' (1.12m)	14/bag; 5 bags/case



Lacoste Ribbed CleanTube™



Jersey Textured CleanTube™