

PROSAT® Presaturated Wipes

Meltblown polypropylene wipes

Contec's PROSAT® Presaturated Wipes are made using meltblown polypropylene (MBPP) fabric and various blends of IPA and DI water. Meltblown polypropylene is exceptionally clean, free from additives of any kind and has a very low concentration of sodium. An excellent choice for general surface cleaning where fast drying times are desired, PROSAT® wipes are low in non-volatile residues as well as particles and fibers. The use of presaturated wipes provides maximum process control, reduces VOC emissions and solvent use up to 35% compared to spraying.



Product Information					
Material	100% polypropylene				
Construction	Meltblown nonwoven				
Saturation Solution		95% IPA/ 5% DI water		85% IPA/ 15% DI water	
	70% IPA/ 30% DI water	91% IPA/ 9% DI water	50% IPA/ 50% DI water	80% IPA/ 20% DI water	
Attributes (units)	Typical Value*	Typical Value*	Typical Value*	Typical Value*	Test Method
Basis weight (g/m ²)	36	34	n/a	36	—
Non-volatile residue, NVR					
In deionized water (g/m ²)	0.010	0.040		0.01	IEST-RP-CC004.2, Sec. 6.1.2
In isopropyl alcohol (g/m ²)	0.070	0.020	n/a	0.07	
Specific ions					
Sodium (ppm)	3.0	0.08	n/a	3.0	IEST-RP-CC004.2, Sec. 6.2.2
Chloride (ppm)	5.0	8.63		5.0	
Particles, readily releasable P ≥ 3.0µm (x10 ⁶ /m ²)	5.8	23.9	n/a	19.7	IEST-RP-CC004.2, Sec. 5.1
Fibers > 100µm (x10 ³ /m ²)	6.3	0.145	n/a	6.3	IEST-RP-CC004.2, Sec. 5.2

Part no.	Description	Size	Packaging
PSP70005	PROSAT Presaturated Wipes (714) Presaturated with 50% IPA/50% DI water	11" x 17" (280 x 432 mm)	50/bag; 20 bags/case
CSPP0001	PROSAT Presaturated Wipes (ERHT) Presaturated with 70% IPA/30% DI water, quarter folded, foil pouch	16" x 17" (406 x 432 mm)	50/bag; 12 bags/case + 1 SATBOX
PS-850	PROSAT Presaturated Wipes (ERHT) Presaturated with 70% IPA/30% DI water	8" x 8" (203 x 203 mm)	50/bag; 50 bags/case
PS-911	PROSAT Presaturated Wipes (ERHT) Presaturated with 70% IPA/30% DI water	9" x 11" (230 x 280 mm)	30/bag; 50 bags/case
PSPP0043	PROSAT Presaturated Wipes (ERHT) Presaturated with 70% IPA/30% DI water	9" x 11" (230 x 280 mm)	50/bag; 40 bags/case
PSPP0035	PROSAT Presaturated Wipes (ERHT) Presaturated with 70% IPA/30% DI water, quarter folded	11" x 17" (280 x 432 mm)	50/bag; 12 bags/case
PS-LPP-7030	PROSAT Presaturated Wipes (ERHT) Presaturated with 70% IPA/30% DI water, quarter folded	16" x 17" (406 x 432 mm)	50/bag; 15 bags/case
SMPP0007	PROSAT Presaturated Wipes (714) Presaturated with 70% IPA/30% DI water	11" x 17" (280 x 432 mm)	50/bag; 20 bags/case
PS-PP-8020	PROSAT Presaturated Wipes (ERHT) Presaturated with 80% IPA/20% DI water	11" x 17" (280 x 432 mm)	50/bag; 20 bags/case
PS-PP-8515	PROSAT Presaturated Wipes (ERHT) Presaturated with 85% IPA/15% DI water	11" x 17" (280 x 432 mm)	50/bag; 20 bags/case
PS-PP-955IDI	PROSAT Presaturated Wipes (ERHT) Presaturated with 95% IPA/5% DI water	11" x 17" (280 x 432 mm)	50/bag; 20 bags/case
PS-LPP-8515	PROSAT Presaturated Wipes (ERHT) Presaturated with 85% IPA/15% DI water	16" x 17" (406 x 432 mm)	50/bag; 15 bags/case
PSP70002	PROSAT Presaturated Wipes (714) Presaturated with 85% IPA/15% DI water, quarter folded	11" x 17" (280 x 432 mm)	50/bag; 20 bags/case
PS-919	PROSAT Presaturated Wipes (ERHT) Presaturated with 91% IPA/9% DI water	9" x 11" (230 x 280 mm)	30/bag; 50 bags/case
PSPP0047	PROSAT Presaturated Wipes (714) Presaturated with 91% IPA/9% DI water	9" x 11" (230 x 280 mm)	50/bag; 40 bags/case
PSPP0048	PROSAT Presaturated Wipes (714) Presaturated with 85% IPA/15% DI water	9" x 11" (230 x 280 mm)	50/bag; 40 bags/case
CSCN0002	SATBOX for 11" x 17" quarter folded wipes, labeled w/blue IPA SATWIPES® label	9.6" x 6.25" x 3" (244 x 159 x 76 mm)	4/case
CSCN0005	SATBOX for 16" x 17" quarter folded wipes, unlabeled	9.6" x 9.25" x 3" (244 x 235 x 76 mm)	12/case

*Notes

- a) The data shown are typical values and should not be used as product specifications.
- b) Valid product comparisons may only be obtained through side-by-side testing in the same test facility, under similar conditions.
- c) Current and/or comparison data may be available. Please contact a Contec sales representative for details.

TDS016ISP | 071723

Copyright © 2023 Contec, Inc. All rights reserved.