

# CleanTube™ Wipes

## 100% polyester knit tubular wipes, black

Contec’s CleanTube™ tubular wipe brings the cleanliness of controlled environment laundering to the automotive industry. Constructed of 100% polyester knit, CleanTube wipes are ideal for many surface preparation applications in automotive manufacturing, as well as in other industries.

The durable, solution-dyed black polyester fabric provides excellent sorbency. The heat cauterized edges naturally roll-up, reducing the potential for contamination from cut fibers, and the high-stretch fabric allows for cleaning easily in tight spaces. This black colored tube provides a sharp contrast to white colored sealant during excess sealant removal applications.



Product Information		Benefits	
Material	100% polyester		
Construction	Knit		
Attributes (units)	Typical Value*	Test Method	
Basis weight (oz/yd <sup>2</sup> )	16		
Sorbptive rate (seconds)	25		
Non-volatile residue, NVR In isopropanol (g/m <sup>2</sup> )	0.167		
Particles, readily releasable P ≥ 0.5µm (x10 <sup>6</sup> /m <sup>2</sup> )	0.126	IEST-RP-CC004.2, Sec. 5.1	
Fibers > 100µm (x10 <sup>3</sup> /m <sup>2</sup> )	0.0325	IEST-RP-CC004.2, Sec. 5.2	

Part no.	Description	Size	Packaging
LWTW7L10GBLACK	CleanTube Wipes Tubular lacoste ribbed knit	7" x 10" (178 x 250 mm)	100/bag; 50 bags/gaylord;
PN-99	Polynit Wipes Flat stacked	9" x 9" (230 x 230 mm)	75/bag; 16 bags/case
PN-99B	Polynit Wipes Bulk	9" x 9" (230 x 230 mm)	300/bag; 4 bags/case
PN-99B/150	Polynit Wipes Bulk	9" x 9" (230 x 230 mm)	150/bag; 8 bags/case
PN-1212	Polynit Wipes Flat stacked	12" x 12" (305 x 305 mm)	75/bag; 10 bags/case;
PN-1212B	Polynit Wipes Bulk	12" x 12" (305 x 305 mm)	150/bag; 4 bags/case;

Notes

- a) The data shown are typical values and should not be used as product specifications.
- b) Valid product comparisons may only be obtained through side-by-side testing in the same test facility, under similar conditions.
- c) Current and/or comparison data may be available. Please contact a Contec sales representative for details.