



Slinger™ User's Guide


Instructions for assembling and installing Contec's Slinger and Slinger frame for 2726 Bucket



Slinger mesh, rods & frame



Step 2/ Place first Slinger frame piece onto bucket



Step 6/ Install the Slinger rods into the second frame piece.

Slinger™ Assembly and Installation:

1. Remove bucket, Slinger mesh fabric, stainless steel Slinger rods (one short and one long), and stainless steel Slinger frame (two pieces) from their packaging. Properly dispose of packaging materials.

NOTE: There is a short and long Slinger rod. The lengths of these rods match the length of the sleeves on the Slinger mesh fabric.

2. Place one piece of the Slinger frame onto a corner of the bucket. The frame should be positioned so that the end of the frame with a rod support bracket on the tip is near the pivot point of the bucket handle (in the center of the short side of the bucket). When in position, press the frame piece onto the top edge of the bucket until the edge of the bucket seats completely into the entire channel of the Slinger frame.
3. Set the second Slinger frame piece aside for use after installing the Slinger mesh and rods, as follows.
4. Slide the long Slinger rod through the long sleeve of the Slinger mesh fabric, and slide the short Slinger rod through the short sleeve.
5. Install the Slinger rods into the rod support holes of the Slinger frame that is already on the bucket. The long rod should be positioned along the center of the bucket. Place the same ends of both rods into the corresponding holes of the Slinger frame at the same time.
6. While holding the Slinger mesh fabric and rods in place (made easier by pressing the rods against the rod-stops of the Slinger frame), place the second Slinger frame piece onto the Slinger rods, with the rods slipping into the appropriate holes on the Slinger frame.
7. While keeping slight pressure on the Slinger rods with the second Slinger frame piece, install the second Slinger frame piece onto the top edge of the bucket as with the first, making sure that the bucket seats completely into the entire channel of the Slinger frame.
8. Be sure that the Slinger frame pieces are completely installed on the top edge of the bucket. The Slinger mesh should be evenly suspended between the Slinger rods.

NOTE: The Slinger mesh is intentionally designed to slope slightly from one end to the other, in order to speed liquid drainage from within the curved metal frame. This is normal.



ph: +1-864-503-8333
www.contecinc.com